HITACHI

HITACHI

14bit A/D DIGITAL CAMERA

00

HITACHI

Preiminary

The Hitachi Z-3500 offers Professional users the best combination of features and price. The Z-3500 incorporates added new technology advancements, performance and functionality that continue the tradition and popularity the Z-series Hitachi cameras are known for.

Budget-conscious users now benefit from the use of Hitachi's own DSP IC's and the implementation of the latest generation of 14-bit Analog to Digital Converters; technologies which add up to high-quality images with superb resolution and low noise qualities.

Outstanding Features

Resolution 900TV line

An outstanding 900 TV Lines of resolution are achieved through the use of Hitachi's own Digital Signal Processor and new 2/3-inch, 470,000 pixel IT-CCDs.

Next-Generation DSP

Hitachi's unique DSP technology encompasses the video digital processing and the encoder into a single LSI device. This single chip 3 million gates 0.18μ m DSP design reduces the size, power consumption and greatly enhances stability.

The 14 bit A/D converter and 20 to 30 bit DSP processing provide a high S/N ratio and wide dynamic range.

Signal to Noise Ratio 65dB

With the new digital noise reduction and low noise DSP technology, a S/N ratio of -63dB(DNR off)/ -65dB(DNR on) is achieved. This new technology assures clear low noise images while operating in the high gain modes.



Sensitivity - F11(2000 lx)

A total of +36dB of gain is available for reproducing low light scenes down to 0.5 lx (F1.4). The +36dB gain is a combination of +24dB high gain and +12dB digital gain.

Versatile CCD Shutter

Four modes of shutter operation are provided : Five Preset electronic shutter speeds, Lock Scan to image computer monitors without flicker, Auto Electronic Shutter (AES) maintains the video level with a fixed lens f-stop, and CC Frame offers improved vertical resolution.

Digital Processing Improves Image Highlight Quality

Dyna-Chroma and Auto Knee

The auto knee provides a wide dynamic range by compressing the video above 100%. Dyna-chroma restores color saturation to scene highlights above 100%.

Automatic Flesh Tone Detail

Flesh tone detail smooths and softens facial lines and blemishes without sacrificing overall scene detail. Automatic flesh tone detail provides an easy and fast means to optimize flesh tone detail.

Variable Detail Boost Frequency

The detail center frequency is user selectable to match the detail signal to the scene.

6-Vector and Linear Matrix

The 6-vector color corrector and linear matrix provide the user a wide latitude in subjective image color control. The linear matrix provides overall color control and the 6-vector color corrector provides independent control of the hue and saturation for each of the three primary and three secondary colors.





Special Gamma

Adjusts the initial gamma gain to optimize the reproduction of the dark areas in a scene.

Gray Scale Automatic Setup

This "through the lens" automatic is used in combination with a standard gray scale chart to automatically setup gain, gamma, black and flare. Markers are provided in the viewfinder to aid in the positioning of the gray scale chart and the iris is automatically adjusted to the correct video level.

Automatic shading

Automatic shading corrects white vertical shading at the push of a button. This feature provides separate setups to optimize the X1 and X2 lens extender positions.

Extensive User-Friendly Features

Quick Focus

Quick Focus automatically opens the iris then sets the video level with the electronic shutter. With the resulting shallow depth of focus, the exact focus point can be set easily.

• Two User-Programmable Switches (CS-1, CS-2)

The user can assign full auto, quick focus or contrast to either of the two programmable switches for ease of operation.

• Full Auto

The built-in automatic electronic shutter (AES) and automatic iris maintain the video level even with radically changing light levels. Real-time automatic white balance corrects for color temperature variations due to changing types of lighting conditions.

- Four scene files are provided to store and recall functions such as gain, detail, masking, gamma and other settings.
- Title text are displayed on the color bar display.
 - Audio test tone (1kHz) is output when color bars are selected.

Viewfinder Displays

• The viewfinder displays the function tree menus.

Status display

Indicators for zoom and focus (with compatible lenses), iris F-stop, color temperature for auto white balance and other functions are displayed.

• Two mode zebra

Menu selection of over-level or between range zebra is provided.

• Viewfinder V-Detail

Vertical detail is enhanced in both the 1.5-inch VF (GM-9) and 5-inch VF (GM-51) viewfinders for easy lens focus. Horizontal detail is also provided.

High Performance 1.5 inch Viewfinder (GM-9)

- The 600 TV line resolution assures easy focus.
- Large aperture lens improves viewfinder viewing.
- Front-back, left-right and tilt positioning is provided for optimum user comfort. The bayonet mount provides a direct connection to the camera eliminating the need of a cable.
- Rotates to a perpendicular position for convenient carrying.

Advanced Ergonomics

- New low center of gravity design.
- Main operation switches are grouped forward for easy access.
- Featherweight design (camera head 2.6 kg) is ideal for portable use.
- Adjustable shoulder pad position and non-slip finish provide on-the-shoulder balance, comfort and confidence.





FLEXIBLE CHOICE OF REMOTE CONTROL UNITS

Suggested System Configurations

Studio system: RU-Z35 Camera Base Station, CA-Z35 Camera Adaptor, RC-Z3/RC-Z21A/ RC-Z33 Camera Control Panel, and GM-51 5-inch viewfinder.

Studio Operation Enhancement

The optional EA-Z35 Extension Adaptor adds (used with the RU-Z35) intercom channel PD/ENG switching, prompter video output and a call button to alert a video operator by the Camera Base Station or Camera Control Panel.





Camera Control Panel RC-Z3

ACCESSORIES



CA-Z35 Camera adaptor for RU-Z35



GM-51 5-inch view finder



EA-Z35 Extension adaptor for CA-Z35





AT-30 View finder adaptor for GM-51



 $A20 \times 8.6BRM-24$ Zoom lens



MH-Z3 Microphone holder



MT-12MF



 $\begin{array}{l} \textbf{YJ19} \times \textbf{9BKRS} \\ \textbf{Zoom lens} \end{array}$



C-300MA Microphone cable



TA-Z3 Tripod adaptor



TU-Z3A Triax base station with RC-Z3 (option)



GM-9 1.5-inch view finder



C-502KAB/C-152KAB/C-103KAB



CX-Z3A Triax adaptor rear view



RC-Z33 Camera Control Panel

The RC-Z33 Camera Control Panel has 11 potentiometers to control the Z-3500 camera.

RU-Z35 Camera Base Station

The new Camera Base Station model RU-Z35 includes all the essential camera system features and functions and offers a high picture quality in demanding production studio applications.

Production Switcher independent Green Tally and Red Tally are available as standard features.

Prompter video and power at the camera head are also standard functions offered. Camera Base Station BU-Z35



Back



SPECIFICATIONS : Z-3500 Camera Head

-	
Color System	PAL-B
Optical system	2/3" F1.4 prism
Pickup system	RGB 31T- CCD, 2/3"Image format
Imaging size	4:3 8.8 x 6.6mm
Picture elements (pixels)	Total 795(H) x 596(V) Effective 752(H) x 582(V)
Sync system	Internal or genlock
Horizontal resolution	900 TV lines
Signal-to-noise ratio	63 dB typical (Gamma : 1, DTL : off, Gain : 0 dB, Y-OUT, DNR : off) 65 dB typical (Gamma : 1, DTL : off, Gain : 0 dB, Y-OUT, DNR : on)
Standard sensitivity	F11 at 2000 lx
Minimum illumination	0.5 lx F1.4 / 0.8 lxF1.8 (Gain : +24dB, digital gain : on)
Gamma correction	0.35 to 1.0 (ON/OFF switchable)
Geometric distortion	All zones : less than measurement limit (excluding lens)
Registration	All zones : less than 0.05% (excluding lens)
Optical filters	3200K, 5600K +1/16ND, 5600K, 5600K+1/64ND
Vertical detail correction	2H
DTL controls	DTL LEVEL, DTL FREQ, FLESH TONE, LEVEL DEP, CRISP, H-V BAL, SOFT DTL, etc.
Lens mount	Bayonet (Backfocus : 48mm in air)
Gain selector	Low : 0dB Mid : +6/ +9 / +12dB High: +12/ +18 / +24dB Remote mode : 0dB to +24dB (3dB steps)
Digital-Gain function	Gain is increased +6dB, +12dB by Internal processing of DSP
Scene file	4 scene files Items: gain, DTL, masking, gamma, electronic shutter, auto iris mode, contrast, etc.
Electronic shutter	Preset mode 1/60, 1/250, 1/500, 1/1000, 1/2000 CC FRAME Lock SCAN mode : approx 1/50 to approx. 1/2000 (in 1H steps); Automatic Electronic Shutter (AES) mode : (up to 4 lensstops)
Input signals	1.Genlock input (BNC or multi-connector) : VBS 1.0Vpp (\pm 3dB or black burst/75 Ω (sync 0.3 \pm 0.1Vpp, burst : 0.3 \pm 0.1Vpp) 2.Viewfinder AUX input (multi-connector) : VBS 1.0Vpp \pm 3dB / 75 Ω
Output signals	1. Video output(BNC) VBS 1.0Vpp / 75Ω 2. VTR output 1 (multi-connector) VBS 1.0Vpp / 75Ω 3. VTR output 2 (multi-connector) as (composite signal: VBS 1.0Vpp / 75Ω a : Composite signal: VBS 1.0Vpp / 75Ω bs (VC output : Y: 1.0Vpp / 75Ω, C: 0.3Vpp (burst), c: RGB output : RGB : 0.7Vpp / 75Ω d : Component output: VS: 1.0Vpp / 75Ω r, RY, BY: 0.52SVpp / 75Ω RY, BY: 0.52SVpp / 75Ω 4.Monitor output (BNC) VBS 1.0Vpp / 75Ω, with charactors 5.Audio output (multi-connector)
Ambient temperature	Operating: -10 to +45°C (+14 to +113F) Storage: -20 to +60°C (-4 to +140F)
Power requirement	12 V DC (+10.5VDCto+17VDC)
Power consumption	Approax. 9.8W (excluding GM-9, camera adapter)
Dimensions	125(W)x268(H)x160(D)mm (excluding camera adapter)
Mass	Approx. 2.6kg (5.7 lb) (excluding GM-9, lens and camera adapter)

SPECIFICATIONS : RU-Z35		
OUTPUT signals	LINE 1 / 2	VBS 1.0Vp-p/75Ω
	SDI output	0.8Vpp/75Ω
	MON	VBS 1.0Vp-p/75Ω
	RGB R-Y, Y, B-Y	V : 0.7Vp-p VS1.0Vp-p/75Ω
	AUDIO output	OdB, 600 Ω , one system
INPUT signals	PROMPT	VBS 1.0Vp-p/75 Ω or loop-through
	AUX VIDEO	VBS 1.0Vp-p/75 Ω or loop-through
	GENLOCK	BB 0.6Vp-p/75 Ω or loop-through
	TALLY	Closure or Voltage(24V)
	INTERCOM	XLR-5pin Corresponding to dynamic mic
Power requirements		230 V AC, 50 Hz
Power consumption		Approx. 125W
Maximum cable length		Approx. 300m (980 ft)
Ambient temperature		5 to 40°C (41 to 104°F)
Dimension		482(W) x 88(H) x 300(D)mm (19.0 x 3.5 x 11.8 in)
Mass		Approx. 9kg(20 lb)

SPECIFICATIONS : TU-Z3A/CX-Z3A

Video band width (Base band)	Y signal : 10 MHz PB,PR signal : 5 MHz RET, PROMPT signal : 5 MHz
AmbientTemperature	Operating : TU-Z3A 0 to +40 °C CX-Z3A : -10 to +45 °C Storage : -20 to +60 °C
Power supply voltage	AC230 V 50 Hz
Power consumption	approx. 130 W (AC operation, includeing Z-3500/GM-51 and AUX POWER OUT 50 W) TU-Z3A : approx. 25 W (DC operation) CX-Z3A : approx. 30 W (DC operation, includeing Z-3500/GM-51)
Dimensions	TU-Z3A 212(W) x 163(H) x 381(D) mm CX-Z3A 135(W) x 196(H) x 215(D) mm
Mass	TU-Z3A Approx. 9.0 kg (19.9 lb) CX-Z3A Approx. 3.0 kg (6.6 lb)



CAUTION : To ensure safe operation, please read the instruction manual before using this product.

These Specifications are subject to change without notice.

Head Office : 14-20.Higashi-Nakano 3-chourne, Nakano-ku, Tokyo 164-8511, Japan Phone : +81 (0) 3-3366-8111, Fax : +81 (0) 3-3365-9119 URL: http://www.h-okusai.com

 Unter Integration

 Beijing Fortune Building S. Dong San Huan Beidu, Chao Yang District, Beijing, 100029 China Phone: +86 (0) 10-6590-8758/8766, Fax: +86 (0) 10-6590-8757

 Hitachi
 Denshi
 America, Ltd.
 URL:http://www.hdal.com

 Hitachi
 Denshi
 America, Ltd.
 URL:http://www.hdal.com

 West Office
 B7 Orossways Park Drivo, Mootbury, Newsbort, 1797, U. S. A.

 Midwett Sales
 Phone: (+1) 310-328-6116, Fax: (+1) 510-328-6252

 Midwett Sales
 Phone: (+1) 303-334-4115, Fax: (+1) 516-496-3718

 South Sales
 Phone: (+1) 316-382-4425, Fax: (+1) 516-496-3718

 Parts Center
 Phone: (+1) 316-482-4425, Fax: (+1) 516-921-0993

 Latin Sales
 Phone: (+1) 316-482-4425, Fax: (+1) 516-921-0993

 Usits Denshi
 Canada, Ltd.
 URL:http://www.hitachidenshi.ca

 Hitachi Denshi Canada, Ltd.
 URL:http://www.hitachidenshi.ca

 Head Office
 1 Select Avenue Unit#11 Scarborough, Ontario M1V 513, Canada, Phone : (±1) 186-299-5900, Fax: (±1) 416-299-6450

 Eastern Office
 5795 Chemin St. Francois St. Lauren, Ouebec H4S 186, Canada Phone : (±1) 186-325-6667, Fax: (±1) 514-335-1664

Hitachi Denshi (Europa) GmbH Head Office : Weiskircher Straße 88, Jügesheim D-63110 Rodgau, Germany Phone : +49 (0) 6106-69920, Fax : +49 (0) 6106-16906 URL : www.hitachi-service.net General email address : webmaster@hitachi-service.net General email address : webmaster@hitachi-service.net HetaChi Denshi (U, K.), Ltd. Head Office Windsor House, Britanni Road, Watham Cross, Hertfordshire EN8 7NX, United Kingdom Phone: +44 (0) 845-121-2717, Ray: +44 (0) 845-121-2718. Leeds Office Brookfield House, Seltpurg Road, Garforth, Leeds LS25 1NB, United Kingdom Phone: +44 (0) 113-287-4400, Past -+44 (0) 113-287-4600 URL: vww.hitachi-denshi-uk.com General email address: sades@hitachi-denshi-uk.com JMI-0062

